

Setting the clock and date on 4.0AR

1. Turn on power to console with power switch on the back of the console
2. Press and hold the clock/ date button down for 3-5 seconds until the console beeps twice and the first digit of the time is blinking.
3. Use the up or down arrow on the toggle pad to adjust the hour.
4. Press enter so the minutes place is flashing.
5. Use the up or down arrows on the toggle pad to adjust the minutes.
6. Press enter so the month flashes and use the up or down arrows to choose the month
7. Press enter so the date is flashing and use the up or down arrows to choose the correct date.
8. Press enter and the year will flash. Use the up or down arrows to choose the correct year.
9. Press enter and "AM" will flash on the console. Use the up or down arrow to change it to PM.
10. Press and hold enter to save the information once it has all been inputted.